

AHC - QHC SERIES

Technical Manual Counting Scale

TSCALE

Contents

| | |
|------------------------------------|----|
| 1. Precautions..... | 3 |
| 2. Installation..... | 4 |
| 3. Name and functions..... | 6 |
| Key board..... | 6 |
| Display..... | 8 |
| 4. Operation..... | 9 |
| Power ON/OFF | 9 |
| Zero..... | 9 |
| Tare..... | 9 |
| 5. Parts Counting | 10 |
| Setting unit weight..... | 10 |
| Entering a known unit weight..... | 10 |
| Parts counting..... | 10 |
| Automatic part weight updates..... | 10 |
| Setting high / low limits | 11 |
| Checking Alarm..... | 11 |
| Accumulation..... | 11 |
| Automatic Accumulated Totals..... | 11 |
| Auto Off | 11 |
| Display back light..... | 11 |
| 6. Parameter..... | 12 |
| Parameter block..... | 12 |
| Setting parameters | 12 |
| 7. RS232 Protocol..... | 18 |
| Specification..... | 18 |
| Connector..... | 18 |
| Commands..... | 18 |
| Communication..... | 18 |
| 8. Error codes..... | 21 |
| 9. Drawing..... | 22 |
| Parts list..... | 23 |
| 10. Dimension..... | 24 |
| 11. Specifications..... | 24 |
| Load cell specifications..... | 25 |

1. Precautions

- Read this manual before operating or servicing this equipment.
- Follow these instructions carefully.
- Disconnect this equipment from the power source before cleaning of performing maintenance.
- Keep the manual for your future reference.
- Avoid extremes of temperature. Do not place in direct sunlight or near air conditioning vents.
- Avoid unsuitable tables. The tables or floor must be rigid and not vibrate. Do not place near vibrating machinery.
- Avoid unstable power sources. Do not use near large users of electricity such as welding equipment or large motors.
- Avoid high humidity that might cause condensation. Avoid direct contact with water. Do not spray or immerse the scales in water.
- Avoid air movement such as from fans or opening doors. Do not place near open windows.
- Do not stack material on the scales when they are not in use.
- Keep the scales clean.

2. Installation

Unpacking

Carefully take the balance out of its package, make it sure its not damaged and all accessories are included.

Accessories,



1. Balance
2. Adaptor
3. Stainless steel pan
4. Product manual

Keep the packaging material for your future use.

Level Adjusting

Place the scale on a table.

Check the water mark. If, bubble is not centre adjust the leveling feet until reach centre. Check the level when you change the location.



Connect Adaptor



- To charge the battery insert the adaptor pin to jack. Adaptor simply plug into the mains power. The scale no needs to be turned on.
- The battery should be charged for 12 hours for full capacity.
- Right side of the display there is an LED to indicate the status of battery charging. When the scale is plugged into the mains power the internal battery will be recharged. If

the LED is green, the battery has a full charge. If it is red, the battery is nearly discharged and if yellow, the battery is being charged.

- Do not use any other type of power adaptor than the one supplied with the scale.
- Verify that the AC power socket outlet is properly protected.

Note: Please charge the battery before using the scale for the first time.











3. NAMES AND FUNCTIONS

Overall View



Key Board



| Keys | Press this key to |
|---|---|
|  | Enter individual unit weights and the present tare |
|  | Clear incorrect entries and error conditions |
|  | Returns the display to zero. |
|  | Enter the clear tare weights, Storing the current weight as tare value. Subtracting the tare value from the total weight and displays the result as net weight. |
|  | Add the current count data aggregated. Also evokes the memory if pressed to balance empty. Can add up to 99 values, or until it reaches the maximum displayable digits. |
|  | Recall the accumulator memory. |
|  | Enter the numbers of items, used for the unit weight. |
|  | Manually enter the weight of sample, also changes the unit if they are enabled. |
|  | To set the upper limit of the number of items counted. |
|  | Used to print the results to PC or printer |

Display

LCD



Overlay



BATT : Battery indicator. When it's illuminated, battery should be recharge.

Net : Net weight indicator. When the scale has been tared and the display is in NET mode

Stable : Stable indicator. When it's illuminated, the scale is stable.

Zero : Zero indicator. When it's illuminated, the scale is in Zero point

Sample : Sample indicator. If the scale that considers the number of samples is insufficient for an accurate count.

U. Wt : Unit weight Indicator. If the Unit Weight is not sufficient for an Accurate count it will illuminate.

LED : Battery charging status, when the scale is plugged into the mains power the internal battery will be recharged. If the LED is green, the battery has a full charge. If it is red, the battery is nearly discharged and if yellow, the battery is being charged.

4. OPERATION

Initial Start-Up

Warm-up time of 15 minutes stabilizes the measured values after switching on.

1. Power ON/OFF

Power switch is located below the right side of the scale. Switch on the scale by pressing on/off. The display is switched on and the self test is started. If you want to switch off press again the key.

2. Zero

Environmental conditions can lead to the balance exactly zero in spite of the pan not taking any strain. However, you can set the display of your balance to zero any time by pressing zero key and therefore ensure that the weighing starts at zero.

3. Tare

The weight of any container can be tared by pressing tare button so that with subsequent weighing the net weight of the object being weighed is always displayed.

- Load weight on the pan.
- Press tare key. Zero is displayed, and tare is subtracted.
- Remove weight from the platform. Tared weight is displayed. It can set only one tare value. It can display with a minus value.
- Press tare key. Zero is displayed, tare weight is cleared.

5. PARTS COUNTING

1. Setting Unit Weight

- For this function you need to know the average weight of objects to count. This value can be obtained by weighing a known number of pieces so that the balance calculation, the average unit weight or manually entered through the keyword.
- Both scales can be used to calculate the unit weight or the manual input that can be used to count on both scales. It can increase the precision of the unit weight at any time during the process of counting by the count displayed and pressing **Smpl.** Make sure that the amount shown is the amount on the scale before pressing the button.
- The weighing may be amended on the basis of greater numbers of samples improves the accuracy of counting large quantities.

2. Entering a Known Unit Weight.

If the unit weight is known can be entered from the keyboard.

- Enter the value of unit weight using the numeric keys then press **U.Wt.** While the display flashes. If nothing is done within seconds, the display "UNIT WEIGHT" back to the previous value, otherwise it shows the new value entered.
- The sample is then stored in the balance and the net weight is displayed together with the calculated amount based on the weight per unit.

3. Parts Counting.

Weigh a sample to calculate the unit weight to determine the average weight of items to count, put a known number of pieces on the scale and insert their content. The balance of the total weight divided by the number of samples and displays the unit weight.

- Zero the scale by pressing the zero if necessary. If you use a container, put it on the scale and the tare weight gain by following the steps above.
- Place a known amount of pieces on the scale. When the viewer "Weight" is stable enter the quantity of pieces using the numeric keys and press the **Smpl.** The number of units is shown by the viewer "Count" and the average weight shown is calculated from the viewer "Unit Weight".
- Adding pieces on the scale, increase the weight and count.
- If the scale is not stable, the calculation is completed.
- If the weight is less than zero, the viewer "Count" shows a negative count.

4. Automatic Part Weight Updates

After entering into parts counting, the display shows number of parts corresponding to previous reference weight. So that continuity will be maintained with previous parts counting this was interrupted due to power failure.

5. Setting High / Low limits.

Pressing **Pst** the user can select count or weigh and set limits. For example: Press **Pst** will display "Hi Cnt" pass counting by weighing Press **Tare** "Hi cnt" "1.999" appears at the upper limit current count, press the **CE** to cancel and change if necessary. Press **Tare** "Lo cnt" "0.999" appears lower limit of the current count, press the **CE** to cancel and change if necessary. Back to Press **Tare** weighing limits. ie, possible to delete one or both of the limits. The cancellation of both the limits also disables the function. If weight control is selected on the first display shows "Hi net" and "Lo Net".

5.1 Checking Alarm

Press and hold **CE** will display "Check net" (for weight checking), "Check PCS" (for Count Checking) and "Check off" (for not use) .

6. Accumulation

- The values (weight and counting) displayed may be added to the values aggregated by pressing the **M +**. The "weight" display will show the total weight, the display "Count" will show the total counts aggregated and the display "Unit Weight" shows the number of times Articles are saved in memory. These values will appear for 2 seconds.
- The balance must return to zero or a negative value before another sample can be stored.
- Other products may be added by pressing the **M +** key. It may take up to 99 entries or up to the capacity of the display "Weight".
- To view the total value stored, press the **MR** when the balance is zero. The total will be displayed for 2 seconds,
- To free memory, press **MR** to call the stored value then press the **CE** to clear all values.

7. Automatic Accumulated Totals

After entering into accumulation (by pressing M+), it will store values into memory. The "weight" display will shows total weight and number of accumulation.

8. Auto Off

The scale can set Automatic power off. The function makes power down when a scale is not operated by user to save battery power. It can set different time options. For settings see the parameter.

9. Display-Back light

The scale has the option of back light. It can help to see white background and more bright.


6. PARAMETER

PARAMETER BLOCK

| STEP | DESCRIPTION | DEFAULT |
|---------|-------------------|---------|
| FI CAL | Calibration | |
| F2 dI | Set Division | d 3000 |
| F3 Cnt | A/D Count | |
| F4 AU | Auto Accumulation | AU oFF |
| F5 AZn | Auto Zero Range | 2 d |
| F6 Pin | Set New Pin No | 0000 |
| F7 SPd | Sensing Speed | SPd 7.5 |
| F8 OFF | Auto Power | oF 0 |
| F9 Grv | Local Gravity | 9.79400 |
| F10 bEP | Beep option | Low |
| F11 rSt | Reset | |

SETTING PARAMETERS




Switch on the scale.

Press  during that start up time.

Display will show 'Pin' briefly if PIN is activated. Press the PIN number to get into the parameter menu.

The default PIN number is "0000".


Press the "0" key four times. The display will show "Pin - - - -", then press the Tare key.

This function can be accessed by using the . The weight display will show the name of the function, to enter the function by pressing the  key. At any time you can return to weighing by pressing the .

F1 CALIBRATION

1. Linear Calibrate.

Enter the parameter menu using by password 9999.



Remove the weights; The Linear Calibration procedure is finished. When the calibration is finished, the display will enter into weighing mode.


Calibration Weights for linear Calibration.


| AHC/QHC SERIES | | | | |
|----------------|--------------|--------------|-------------|-------------|
| Model # | AHC/QHC 3000 | AHC/QHC 6000 | AHC/QHC 15K | AHC/QHC 30K |
| Weight 1 | 1000g | 2kg | 5kg | 10kg |
| Weight 2 | 2000g | 4kg | 10kg | 20kg |
| Weight 3 | 3000g | 6kg | 15kg | 30kg |

2. Normal Calibration

Enter the parameter menu using by password. (Default password "0000")


When the parameter menu show **F1 CAL**





F2 SET DIVISION


Set the scale increment



Press  to select.


F3 A/D COUNT

Showing internal counts




F4 AU ACCUMULATION

Set the Accumulation



Manually send data to RS 232


Data Send to RS232 continues



Press  to select.

F5 AZn AUTO ZERO RANGE


Set the Auto Zero Range.



Press  to select.

F6 Pin PASSWORD


Set the new password (pin number).



Enter the new four digit pin number


Press 

Re-enter the new four digit pin number

Press  P6 Pin

F7 SPd SENSING SPEED


Set the weighing speed



Press  to select.

F8 oFF AUTO POWER

Set the Automatic power off



Press  to select.

F9 Grv GRAVITY

Set the local gravity.




Enter the local gravity by using numeric keys.

Press  to select.

F10 bEP BEEP

Set the beep sound



Press  to select.

F11 rSt RESET

Reset the company default settings



Press  to conform.

7. RS232 PROTOCOL

The AHC/QHC Series of scales can be ordered with an option RS-232 output.

Specifications:

RS-232 output of weighing data
 ASCII code
 4800 Baud
 8 data bits
 No Parity

Connector: 9 pin socket



Pin 2 Output
 Pin 3 Input
 Pin 5 Signal Ground

Commands:

Z<cr><lf> To set the scale to Zero (already works)
 T<cr><lf> To Tare the scale (already works)
 C<cr><lf> To Clear the value
 T5465<cr><lf> To Tare, for example the weight of 5,465kg
 U9,608446<cr><lf> To Transmit, for example the unit weight of 9,608446
 P10<cr><lf> To Transmit the amount of for example 10 peaces on the platform
 and start the sampling process
 M+<cr><lf> To add the present weight with its number of pieces to the memory
 MC<cr><lf> To clear the Memory
 S<cr><lf> The scale will only start the continuous transmission after receiving the
 start command. If the start command is not repeated within 30 Seconds the
 continuous transmission will stop until the next start command comes.

Communication:

T.NO. N<CR><LF>

Here the scale should always transmit the number of accumulations stored in the
 memory

T.WGT. N kg<CR><LF>

Here the scale should always transmit the accumulated weight in the memory

T.PCS. N pcs<CR><LF>

Here the scale should always transmit the accumulated amount of pieces in the
 memory.

The following example shows the protocol under the following conditions:

The 1. package shows the empty scale after the unit weight has been calculated

The 2. package shows the scale after 20 pieces have been loaded

Now the software sends the command M+ for accumulation

The 3. package shows the accumulated values in the memory and the loaded scale

The 4. package shows the accumulated values in the memory and the empty scale

The 5. package shows the accumulated values in the memory and the reloaded scale

Now the software sends the command M+ for accumulation

The 6. package shows the accumulated values in the memory and the loaded scale
The 7. package shows the accumulated values in the memory and the empty scale.
Now the software sends the command MC to clear the memory.
The 8. package shows the empty scale with a clear memory.

1.[RX]

```
ST,GS, 0.0000,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 0pcs<CR><LF>
T.NO. 0<CR><LF>
T.WGT. 0.0000,kg <CR><LF>
T.PCS. 0pcs <CR><LF>
<CR><LF>
<CR><LF>
```

2.[RX]

```
ST,GS, 1.7380,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 20pcs<CR><LF>
T.NO. 0<CR><LF>
T.WGT. 0.0000,kg <CR><LF>
T.PCS. 0pcs <CR><LF>
<CR><LF>
<CR><LF>
[TX]
M+<CR><LF>
```

3.[RX]

```
ST,GS, 1.7380,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 20pcs<CR><LF>
T.NO. 1<CR><LF>
T.WGT. 1.7380,kg <CR><LF>
T.PCS. 20pcs <CR><LF>
<CR><LF>
<CR><LF>
```

4.[RX]

```
ST,GS, 0.0000,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 0pcs<CR><LF>
T.NO. 1<CR><LF>
T.WGT. 1.7380,kg <CR><LF>
T.PCS. 20pcs <CR><LF>
```

<CR><LF>
<CR><LF>

5.[RX]

ST,GS, 3.4760,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 40pcs<CR><LF>
T.NO. 1<CR><LF>
T.WGT. 1.7380,kg <CR><LF>
T.PCS. 20pcs <CR><LF>
[TX]
M+<CR><LF>

6.[RX]

ST,GS, 3.4760,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 40pcs<CR><LF>
T.NO. 2<CR><LF>
T.WGT. 5.2140,kg <CR><LF>
T.PCS. 60pcs <CR><LF>
<CR><LF>
<CR><LF>

7.[RX]

ST,GS, 0.0000,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 0pcs<CR><LF>
T.NO. 2<CR><LF>
T.WGT. 5.2140,kg <CR><LF>
T.PCS. 60pcs <CR><LF>
<CR><LF>
<CR><LF>
[TX]
MC<CR><LF>


8.[RX]

ST,GS, 0.0000,kg<CR><LF>
TARE 0.0000,kg<CR><LF>
U.W. 86.9018 g<CR><LF>
PCS 0pcs<CR><LF>
T.NO. 0<CR><LF>
T.WGT. 0.0000,kg <CR><LF>
T.PCS. 0pcs <CR><LF>
<CR><LF>
<CR><LF>

8. ERROR CODES

| Error Display | Description | Possible Causes |
|----------------------|--------------------|---|
| Err 4 | Zero setting error | Out of the auto zero setting range. (4% of capacity) check the platform empty and re try again. Do the calibration |
| Err 5 | Key board error | Improper operation. Check the key board cable, connector and any damage. |
| Err 6 | A/D out of range | If overloaded, remove the weight make sure platform is installed proper. Check load cell and PCB |
| Err 9 | Unstable reading | Wait for reading stable. Check the load is touching some where. Check any air variation, vibration and RF noise. Check load cell and voltages |


9. DRAWING



PARTS LIST

| NO | Parts Name | Qty | Material | Spec |
|-----------|-----------------------------|------------|-----------------|-------------|
| 1 | Pan | 1 | SST | 230mmX300mm |
| 2 | Pan | 1 | ABS | 230mmX300mm |
| 3 | Battery Cover | 1 | ABS | |
| 4 | Rear Overlay | 1 | | |
| 5 | Name Plate | 1 | | |
| 6 | Battery | 1 | Lead Acid | 6V/4AH |
| 7 | Foam | 1 | CR | |
| 8 | Load cell upper bracket | 1 | Aluminum | |
| 9 | Load Cell | 1 | | |
| 10 | Hexagon Screw | 4 | 20Mn | M4x16 |
| 11 | Load cell lower bracket | 1 | Aluminum | |
| 12 | Hexagon Nut | 2 | | M3 |
| 13 | DB9 Connector | 1 | | Optional |
| 14 | Hexagon nut for D connector | 2 | | Optional |
| 15 | “+” Self thread Screw | 1 | 20 M | 3x8 |
| 16 | AC adaptor jack PCB | 1 | | |
| 17 | Front display overlay | 1 | PC | |
| 18 | Key board | 1 | | |
| 19 | Level bubble | 1 | | 14.7mm |
| 20 | Top Cover | 1 | ABS | |
| 21 | Internal hexagon screw | 4 | | M6x16, 8.8 |
| 22 | Spring Washer (M6) | 4 | | HRC42-50 |
| 23 | Washer (M6) | 4 | 656Mn | 200-300HV |
| 24 | Hexagon nut | 4 | | M4 |
| 25 | Self thread screw | 4 | 20Mn | 4x20 |
| 26 | Main PCBA | 1 | | |
| 27 | Self thread screw | 4 | 20Mn | 3x12 |
| 28 | Front Display PCBA | 1 | | |
| 29 | Insulative washer | 5 | EDPM | 8x3.1x1.2t |
| 30 | Bottom Cover | 1 | ABS | |
| 31 | Power Switch | 1 | | |
| 32 | Foot fixer | 4 | ABS | |
| 33 | “+” Self thread screw | 5 | 20Mn | M4x12 |
| 34 | Foot | 4 | PVC | |

10. DIMENSION



11. SPECIFICATIONS

| | | | | |
|-----------------------|---|------------------|-----------------|-----------------|
| MODEL | AHC/QHC 3000g | AHC/QHC 6000g | AHC/QHC 15kg | AHC/QHC 30kg |
| Capacity | 3kg | 6kg | 15kg | 30kg |
| Readability | 0.05g | 0.1g | 0.2g | 0.5 |
| Tare Range | -3kg | -6kg | -10kg | -30kg |
| Minimum | 1g | 2g | 4g | 10g |
| Repeatability | 0.05g | 0.1g | 0.2g | 0.5g |
| Resolution | Up to 60000 | | | |
| Weighing Units | Kg | | | |
| Housing | ABC Plastic and Stainless Steel platform | | | |
| Interface | RS232 Output optional | | | |
| Operation Temperature | 0°C - 40°C / 32°F - 104°F | | | |
| Power | Power switch 12V/500mA , Battery 6V/4AH | | | |
| Display | 3x6 digits 20 mm LCD display wit white LED back light | | | |
| Dimensions (WxDxH) | 320 x 340 x 125mm / 12.6 x 13.4 x 4.9" | | | |
| Weight | 3.8kg/8.4lb | | | |
| Internal Counts | 600000 | | | |

Load cell specifications

| Model No | NA22 | C2X1 |
|--------------------|-------------------|------------------------|
| Rated Capacity | 6~40 (kg) | 6~50 (kg) |
| Rated Out put | 2.0mV/V± 0.2 mV/V | 2.0 mV/V±0.2 mV/V |
| Excitation Voltage | 15 VDC | 20 VDC |
| IP Level | IP65 | IP64 |
| Material | Aluminium Alloy | Aluminium Alloy |
| Cable | Φ 4x 35 cm | Φ 8.2 four core shield |
| Input Resistance | 390Ω ±15Ω | 420Ω ±30Ω |
| Out put Resistance | 350Ω ±5Ω | 350 Ω ± 5 Ω |
| Temperature Range | -20 ℃ - 60 ℃ | -10 ℃ - 50 ℃ |
| Safe overload | 150 %RC | 150 %R.C |
| Ultimate overload | 200 %RC | 200 %R.C |
| Repeatability | 0.03 %R.O | 0.02 %R.O |
| Creep | 0.03 %R.O/ 3 min | 0.02 %R.O/ 20min |
| Zero Balance | ±0.02 mV/V | ± 0.1 mV/V |

TSCALE is an international supplier with more than 30 years experience in the production and sales of electronic weighing equipments. Products are supplied and serviced from our company locations in the CHINA, TAIWAN and distributed through the world wide dealer network, also we make OEM/ODM products for world wide customers.

TSCALE products are predominantly designed for the laboratory, medical, business and industrial markets.

The product range can be summarized as follows:

- Counting scales for general industrial and warehouse applications.
- Digital weighing/check-weighing scales.
- High performance platform scales with extensive software facilities including parts counting, percent weighing etc.
- Digital electronic scales for medical use.
- Retail price computing scales.
- Floor scales.
- Truck scale.
- Crane scales.
- Weighing indicator for platform scales, floor scales and truck scales.
- Hand push and pull gauge.
- Customize auto weighing systems.

TSCALE and their distributors offer a full range of technical services such as on site and workshop repair, preventative maintenance and calibration facilities. TSCALE operates an approved quality management system and is certified to ISO9001:2000.

Visit our Website at: www.taiwanscale.com

| | |
|--|--|
| Taiwan Scale Mfg. Co., Ltd. 282, Sec.3, Hopping W. Rd. Taipei, Taiwan TEL:886-2-23068203 FAX:886-2-23044354 e-mail: tscale@giga.net.tw | W & P Scales Mfg. (Kunshan) Co., Ltd. No. 99 Shunchang Road Zhoushi, Kunshan Jiangsu China TEL:86-512-57669080 FAX:86-512-57669100 e-mail: sales@taiwanscale.com |
|--|--|

Copyright by Taiwan Scale Mfg. Co., Ltd. All rights reserved. No part of this publication may be reprinted or translated in any form or by any means without the prior permission of Taiwan scale.

Taiwan Scale reserves the right to make changes to the technology, features, specifications and design of the equipment without notice.

All information contained within this publication was to the best of our knowledge timely, complete and accurate when issued. However, we are not responsible for misimpressions which may result form the reading of this material.